

FITTING INSTRUCTION

Part Number APG12 Arcadian Replacement Cables for Catnic/Garador F3c Canopy Doors

WARNING as spring tension is on the door at all times great care must be taken

All work is undertaken from within the garage therefore ensure that all tools required are at hand.

- 1 Close and wedge the door firmly in the opening. Remove the split pin from the top of the link arm and allow the link arm to swing down. Remove all the fixing screws securing the frame track assembly. The frame can now be moved away carefully.
- 2 Remove the 'pop' rivets holding the spring cover in place. Remove all the broken cable.
- 3 To fit the new cable first cut a slot in the top of the frame. Extend the cable using a strong cord or the old wire through the loop of the new cable. Secure the frame and then feed the cable in position around the two pulleys, pull the cable to pretension the door until the clip on the bracket can be clipped over the top of the frame. Refit spring cover plate and reassemble track assembly and the link arm.
- 4 Fit the cable loop over the 'G' bracket on the roller, ensuring the cable is running in the correct position. Pull the cable in the direction shown to release the clip and slowly return it to its position behind the link arm, remove the wedges and check operation of door.

ALL WORK IS UNDERTAKEN AT THE OWNERS RISK

