

FITTING INSTRUCTION

Part Number APH10 Arcadian Replacement Cones and Cables For Henderson Canopy Doors

WARNING As spring tension is on the spring at all times care should be taken to follow instructions carefully.

All work is undertaken from inside the garage so ensure all tools required are at hand. You may need assistance with step (1)

- 1 Ease the spring tension using a .25" dia toggle bar in the clamp at the left hand end of the spring then insert the tension pin supplied in the hole in the spring shaft within the right hand door bracket ensuring that the tension pin rests on TOP of the bracket support.
- 2 Remove the screw at the base of the side jamb channel and the screw holding the bracket half way up (if fitted). This allows removal of the cable from the spindle.
- 3 Using a .125" dia punch carefully drive out the hollow pin on the cone (see note below).
- 4 Remove and discard BOTH old cones and hollow pins. Reassemble using BOTH new cones and pins. Cones are colour coded grey left hand, red right hand. Care must be taken to ensure that the cables exit the cones from the top towards the door frame. Re-attach cables to the spindles taking care to ensure they do not foul the jamb channels or the door arms. Replace the screws in the side jamb channels.
- 5 Carefully remove the tension pin and then check that the cables run on the TOP groove of the cones.

NOTE; If there is insufficient room between the brickwork and the cones to allow removal, wedge the door in position then remove the four coach screws in the door brackets supporting the spring assembly, ease out the spring assembly and slide old cones off the shaft and slide new ones into position then follow step 4

ALL WORK IS UNDERTAKEN AT THE OWNERS RISK