

APZ700 ANTI-BOW KIT

UNPACK AND IDENTIFY ALL PARTS

- 2 off Side anchor brackets
- 1 off Centre support bracket
- 2 off 8mm eye bolts
- 4 off 8mm full nuts for above
- 1 off 5m length of 3mm wire rope (to be cut to length)
- 8 off M8 x 40mm hex head coachscrews

STEP ONE

Very carefully select the fixing points for the side and centre brackets. These must be securely fastened, M8 x 40mm coachscrews are supplied for use when suitable (6mm pilot hole). You will have to supply your own fixings where these are not suitable.

STEP TWO

Fix the two side brackets with the angle towards the centre of the door (see the line sketch below), this will ensure room for adjustment of the eye bolts later. Fix the centre bracket ensuring that it is in line with the side brackets.

STEP THREE

Feed one 8mm full nut right down each eye bolt. Clamp one end of the cable through the loop of one of the eye bolts using one of the 'bulldog' clamps. Feed the eye bolt into one of the side brackets and fasten with one 8mm full nut (only screw nut on until it covers the thread, this will allow for maximum adjustment later). Feed the other eye bolt onto the side bracket as above. Feed the cable through the second eye bolt (do not lift cable onto centre bracket yet), pull tight and secure with second 'bulldog' clamp.

STEP FOUR

Lift cable into centre support. open door and precede to adjust BOTH eye bolts carefully until the bow is removed from the door. Close the door to ensure that it does not bow outwards (if it does remove a small amount of the tension). Fasten the lock nuts that were placed on the eye bolts earlier. Finally before leaving check fixings carefully.

