

FITTING INSTRUCTIONS

- DOOR STAYS -

Pack Contents

Part Code	Part Description	Qty
DPIN 4436	Narrow Door Stays	2 off
DPIN 1122	No14 x 25mm Hex Hd Self Tapping Screws (5.0mm Drill req'd)	12 off
DPIN 0462	Fitting Instructions & Contents List	1 off

FITTING INSTRUCTIONS

1. Open door to form a right angle with frame and wedge in position.
 Note – If the door is required to open further than 90 degrees then both the brackets must be moved closer to the hinges
2. Fix bracket "A" to the rear of the door frame lintel using the No14 x 3/4" Hex Hd S/Tapping screws at the distance shown below. Ensure that the bracket plate is fixed with its front edge square on to the lintel but set back from the rebate.
3. Fix bracket "B" to the back of the door panel in the position shown below using the No14 x 3/4" Hex Hd S/Tapping Screws at the distance shown below.

