

**FITTING INSTRUCTION**

Part number APC20 Arcadian Replacement Cables for Cardale Centre Spring Drum Canopy  
Doors Mk11 and Mk111.

**WARNING** As spring tension is still on the spring take great care.

- 1 First ensure that there is still one cable attached and that the tension is still on the spring.
- 2 Pull on the existing cable until the holes which are in the centre drum line up with the holes in the outer casing. Put a 6" nail or pin straight through both holes, this will lock the tension to enable you to fit a new cable.
- 3 Take the cable, loop first, thread it over the corner small pulley and down the back of the link arm, inside the track, undo the bottom screw of the track, place loop end of the cable over the nylon wheel and onto the spindle. Replace the screw in the track.
- 4 Take the other end of the cable and place it around the centre pulley and into the slot, make sure the cable is over the corner pulley, pull on the cables and let the 6" nail or pin drop out.
- 5 Ensure the cables run smoothly and door not foul the door link arm.

***IT IS RECOMMENDED THAT BOTH CABLES ARE REPLACED***

***ALL WORK IS UNDERTAKEN AT THE OWNERS RISK***