

## FITTING INSTRUCTION

Part Number APC30 Arcadian Replacement Cones and Cables for Cardale 'Compact' Canopy Door

**WARNING** As spring tension is on the spring great care should be taken to follow the instructions carefully.

All work is undertaken from inside the garage therefore ensure that all tools required are at hand.

- 1 Close the door from the inside and insert retaining pin through fixed shaft bush and spring shaft.
- 2 Insert 2 transit screws in each upper weather strip into the side runners. Remove the door and lean it against wall.
- 3 Remove the transit screws and lean side runners against wall.
- 4 Remove the locking plug from the pivot anchor bracket and take cable end out of the retaining hole.
- 5 Remove the roll pin from each cone using a pin punch. Slide both cones off the spring shaft.
- 6 Fit both new cones ensuring they are fitted as drawing below. Fit new roll pins.
- 7 Locate end of the cables in the retaining holes in the pivot anchor brackets, ensuring that the cables are on the correct side of the pivot arm and insert locking plugs.
- 8 Reinsert the 4 transit screws and rehang the door. Remove the transit screws and retaining pin checking that the cables run correctly then test the door action.

