

FITTING AND CARE INSTRUCTION

FOR ALL ARCADIAN 'T' LOCKING HANDLES.

WARNING: When changing your locking handle do NOT lock yourself out of your garage as on some doors if you remove your old lock and then close the door with you on the outside the internal door latches may operate.

- 1 Note CAREFULLY the position of the inside locking mechanism, undo the lock fixing screws and remove the old lock. If a gasket is located between the lock and the door retain this for use with the new lock.
- 2 Refit the new lock in exactly the same manner, using the gasket if available.

CARE OF YOUR NEW GARAGE DOOR LOCK

Your new lock should give many years of trouble free use providing you follow some very simple rules.

- 1 **NEVER** use oil in the key way of the lock, the oil will attract dust and the lock will eventually seize and have to be replaced.
- 2 To lubricate the key way of the lock use graphite powder or rub a pencil on the key and push the key in and out a few times.
- 3 When painting your garage door ensure that you do not allow any paint to enter the key way as the lock will seize and have to be replaced.

ALL WORK IS CARRIED OUT AT THE OWNERS RISK